## Magnescale



## Magnescale

Ihr Fachhandelspartner:



Industriestaße 24 77815 Bühl Tel. 07223/91249-30 Fax. 07223/91249-59 www.gebotech.de info(at)gebotech.de

Magnescale Co., Ltd.

Shinagawa Intercity Tower A-18F, 2-15-1, Konan, Minato-ku, Tokyo 108-6018, JAPAN

Headquaters	: 45 Suzukawa, Isehara-shi, Kanagawa 259-1146, Japan	TEL.+81 (0)463-92-1011 FAX.+81 (0)463-92-1012
Tokyo Office Nagoya Office	: 45 Suzukawa, Isehara-shi, Kanagawa 259-1146, Japan : 2-35-16, Meieki, Nakamura-ku, Nagoya Aichi, 450-0002, JAPAN	TEL.+81 (0)463-92-7972 FAX.+81 (0)463-92-7978 TEL.+81 (0)52-587-1823 FAX.+81 (0)52-587-1848
Osaka Office	: 2-14-6, Nishi-Nakajima, Yodogawa-ku, Osaka 532-0011, JAPAN	TEL.+81 (0)6-6305-3101 FAX.+81 (0)6-6304-6586
International Sales Department Magnescale Americas Inc.	: 45 Suzukawa, Isehara-shi, Kanagawa 259-1146, Japan : 5740 Warland Drive, Cypress, CA 90630, USA	TEL.+81 (0)463-92-7971 FAX.+81 (0)463-92-7978 TEL.+1 (949) 770-8400 FAX.+1 (949) 770-8408
Magnescale Europe GmbH	: Antoniusstrasse 14, 73249 Wernau, Germany	TEL.+49 (0) 7153 934 291 FAX.+49 (0) 7153 934 240

http://www.mgscale.com

The contents of this literature are as of Apr. 2010 This catalog is printed with soy ink. MGS-FB-1004-EN-C

Feedback Scale General Catalog

## **Feedback scale**

Magnescale Co., Ltd.

Contents ...... What is Magnescale?-Selection Guide ...... Measurement Principle Measurement Accurace Installation Method..... Mechanical Specificati Digital Scales (Linear s SR87..... SR84/85.... SR77.... SR74/75.... SR74/75.... SL331/PL60.... SL110/SL130...

Contents

## **Nagnescale PRECISE IN PRECISION**

### Magnescale technology essential for high-performance machine tools

Magnescale, which was developed based on Magnescale's advanced magnetic technology, adapts magnetism to the measurement principle, thus far less affected by the condensation or oil problems commonly found in machine tools and always making stable and precise position measurement possible.

Magnescale with high precision and high environmental resistance supports the front line of your manufacturing.

PL20C/PL25 40
PL81/PL82 41
SL700 Series 42
PL101 43
Digital Scales (Rotary scale) 45
RU77 46
RS310 48
Interpolators 49
MJ100/110
MJ620
MJ820/821 52
MJ830/831 53
List of Adopter Cables 54
Safety 57



### The advantage of scales

A scale is mainly used for machine tools and detects the position of a component such as the stage to which it is installed. Feeding back position information from the scale eliminates errors caused by the following and enables more precise machining to be accomplished.

> Thermal expansion of a ball screw

Pitch error of a ball screw

Backlash

In order to maximize the performance of the scale mounted on a machine tool, it is vitally important to keep a scale signal constant. Magnescale® possesses environmental resistance against contamination by condensation or oil, which makes the signal unstable causing signal errors. Thus, Magnescale<sub>®</sub> is suitable for high-precision position detection.

## What is Magnescale?

### Mounting allowance

Magnescale is constructed so that the sensor for signal detection slides along the guide in the scale with bearings to detect the position. Therefore, it can perform stable, high-precision detection even in the presence of a positional deviation of the scale or head caused by installation or disagreement in parallelism with the machine guides.

### Vibration and impact resistance

Magnescale primarily uses ferrous members as the housing material to protect the detector section, thereby realizing the high vibration resistance and impact resistance characteristics. In the SR80 series, furthermore, it employs multi-point fixation construction in addition to the housing with high rigidity, achieving the industry's top class vibration resistance and impact resistance.

### Thermal characteristics

Magnescale have the same linear expansion coefficient as that of cast iron used for the structure of general machine tools. Therefore, it exhibits the same behavior as the equipment in which it is installed even in environments where temperature changes, making very stable control possible. In particular, the SR80 series scales can be installed in close contact with the equipment; heat exchange with the equipment is effectively achieved, enabling them to attain consistent accuracy even in an environment in which temperature changes occur.

### Resistant to condensation and oil

Magnescale employs the magnetic detection principle, thus far less affected by the condensation or oil problems inherent in machine tools and making stable and high


precision operation possible in severe environments.

### Scale construction

The magnetic signal detection sensor is supported by a bearing, maintaining a non-contact status with respect to the scale material. This bearing runs on the guide incorporated in the scale and detects the equipment's traveling distance. Therefore, the sensor has verv small sliding resistance, enabling the scale to be used even for equipment with small driving force. Moreover, the use of a specially constructed sealing structure helps to prevent dust and dirt from entering inside the scale. In addition, air purging the scale provides further protection.

## Selection Guide

	Measurement length (ML: mm)	Accuracy	Resolution	Output signal	Туре	Cross section	Page	
Linear scale	70mm-2,040mm	3+3ML/1,000µmp-p 5+5ML/1,000µmp-p	0.01μm, 0.05μm, 0.1μm, 0.5μm, 1μm	Absolute serial bidirectional signal	SR77	57.9	30	O
				Incremental serial bidirectional signal	SR75		34	Ō
				A quad B signal Ref. point. Line driver signal	SR74		34	
		3+3ML/1,000µmp-p 5+5ML/1,000µmp-p	0.01μm, 0.05μm, 0.1μm, 0.5μm, 1μm	Absolute serial bidirectional signal	SR87		22	
				Incremental serial bidirectional signal	SR85		26	
				A quad B signal Ref. point. Line driver signal	SR84		26	1 H
Rotary	360°	±2.5second	Maximum output pulse counts 2 <sup>25</sup> =33,554,432p.p.r	Absolute serial bidirectional signal	RU77	ø110	38	



## **Measurement Principle**

### Scale material

The magnetic recording media, or the raw material for scales, was developed as the scale material that realizes high-density recording at high precision, based on Magnescale's magnetic technology that has been cultivated for magnetic tapes and magnetic discs. The scales adopt magnetic metal powder that is used for data storage systems because of its high density and reliability. Its magnetic characteristics are that Br: 0.2 to 0.25T and Hc:

approximately 120 kA/m. The magnetic media form a strong coated surface resistant to cutting fluids and strong alkaline solutions through a hardening process after coating.

### Magnetic powder

Magnetic metal powder used for data storage systems because of its high density and reliability Br: 0.2 to 0.25T, Hc: Approx. 120 kA/m Coating

Resistant to cutting fluids and strong alkaline solutions

Magnetic media's B - H curve

-6000 -4000 -2000

2000 4000

H (x80A/m)

6000

 $\widehat{\mathsf{B}}_{\underline{\mathsf{H}}}$ 



Die head

\* Magnetic material is coated from the tip of the die head onto a scale.


### Signal detection sensor (MR sensor)

The MR sensor is a thin-film sensor patterned on a PWB. It obtains the signal output through the change in the resistance value according to the size of magnetic field leakage from the scale when it moves keeping a certain distance from the magnetic media (scale) to which magnetic signals have been recorded as shown in Figure 1. In this case, however, the signal obtained from the resistance change characteristics of the sensor and the status of magnetic field leakage from the scale also contains distortion components (such as harmonic components) in addition to the sine wave components of the signal pitch. Therefore, the sensor is positioned by shifting it in the operating direction by the distance of 1/6 of another


signal pitch  $\lambda$  (Figure 2). In this case, when third-order harmonic components are observed, the following Equation "A" is established for three-fold periodic signal components because 1/6 of the signal pitch  $\lambda$  is  $\pi/3$  in the periodic phase, and the phase is shifted by 180° with respect to the three-fold periodic signal components of the first sensor, resulting in a reverse signal. The addition of this signal enables the third-order harmonic components to be cancelled out. That is, the combination of these sensors enables harmonic components of the 3n-th orders to be canceled out. In the same way, the combination of multiple units of the sensors also enables the harmonic components of other orders such as 5th and 7th orders to be cancelled out simultaneously.


Figure 1 Arrangement of MR element and magnetic media





In detection sensors, the circuit is generally formed in a bridge structure for stability of the temperature characteristics, etc. as well. In that case, distortion of odd numbered orders are cancelled out by the arrangement of sensors configuring a bridge. Therefore, the use of the bridge structure and the arrangement of the sensor configuration that cancels out harmonic components of the extent of the 3rd, 5th, and 7th orders enable a signal close to sine waves to be obtained. In this way, the scale achieves high precision and high resolution by digitization of electrical interpolation based on a distortion-less signal, coinciding with various electrical signal compensation.





### Figure 2 Structure of high-precision Magnescale

## Incremental signal

An incremental signal is taken as the source of scale performance and does not have absolute positional information of length longer than the wavelength.

In magnetic scales, the S and N poles are regularly arranged at wavelength intervals.

### **Output signal**

- Wavelength: 40, 80 µm, etc.
- Phase angle accuracy: Approx. 0.1 to 0.2 µm

A sinusoidal signal of approx. 1/400 (52 dB) is required.

### **Factors that deteriorate** the phase angle

- DC, gain, or phase variations
- Noise
- Harmonics




Improved signal by the arrangement of MR-element patterns

Improved signal stability, etc. by harmonics and DC cancellation or averaging effects

Automatic consecutive compensation

### Automatic consecutive compensation

Because signals are detected at a maxmum resolution of 0.01 µm, consistent signal detection is achieved at high precision even in case of unmatched parallelism or in an environment in which the temperature varies.



Example of the measurement of Lissajous figure

## Absolute signal


An M code is a code string consisting of two values (0 and 1) known as M sequence and is a cyclic code whose period is N = 2n-1. Where "n" is the order of a primitive polynomial that generates an M code. In the scales, it is the number of digits of M-code bits (value written as "18 bits" above). There is a primitive polynomial for each order, and a code string is serially created from any initial value. As the creation and features of codes, the following shows an example of the order "8" in the condition that the number of digits of a bit = the order of a primitive polynomial Assuming that a creating polynomial is F(x) = x0 + x2 + x3+ x4 and the 8-bit initial value is 00000001, x0 + x2 + x3 + x4 = 0+ 0 + 0 + 0 = 1 ("+" is exclusive OR and the order and bit are in reverse, so that a higher-level order corresponds to a lower-order bit) is established, making the initial value 8-bit's next data "1." The following performs the same logical calculation for data 00000011 in

which the initial value is moved by one, to obtain code 0000001100111110101... In this case, when the code string created by the order "8" is observed as 8-bit data (a set of 8 pieces) one by one, the code strings of 8-bit data can be obtained as follows: 00000001

00000011. 00000110. 00001100. 00011001....

In this case, for M code = cyclic code, when the sequence is cyclically replaced in a period (N = 2n-1), the code word of that sequence always becomes different. That is, the same value of 8-bit data is never presented. Moreover, the code string is composed of apparently random code strings, which are not arranged in an ascending or descending order or in other rules as seen from the example above.

### **Configuration of absolute** encoder detection M codes are non-repetitive codes in which n-bit M codes are



created by a generating polynomial of n bits and that there is no identical code among 2n-1 data. Because codes of 2n are required for a rotary encoder, it adopts the 2-track M-code system that adds 0 (all 0).

- Lamda: 40, 80 microns
- Number of M-code bits: Up to 18 bits

Figure 1 below: Example of 4-bit codes

### Incremental/absolute signal record reproduction to signal composition

- Phase angle in  $\lambda$  is calculated from an incremental signal and taken as positional information in λ.
- An address in  $\lambda$  is calculated from each absolute signal and an M code is recognized by

M-code sensors (multiple). The M code is decoded into an address in  $\lambda$ .

- Both data are added.
- Data format conversion to communication protocol
- Communication (Figure 2 below)

### Accuracy

The grating of an incremental signal and the bit information of an absolute signal of the scale are written to a magnetic track using the recording head. For the recording head position during this write, the writing position of each signal is determined based on the

position information of a light-wave interferometer using the He-Ne stabilized laser. Therefore, the position of each signal on the recording head (= accuracy) can be determined very accurately. The accuracy of the completed magnetic scale into which a detecting

head is incorporated is also measured by comparing it with the positional information of the light-wave interferometer using the He-Ne stabilized laser, which becomes accuracy data.


## Traceability

The He-Ne stabilized laser, the standard for accuracy measurement, is frequency calibrated in-house using the "633-nm iodine molecular absorption line wavelength stabilization Helium neon laser device for length," which is the specified secondary standard

of Magnescale. This specified secondary standard is calibrated by the specified standard of the National Institute of Advanced Industrial Science and Technology (AIST), a national standard. In this way, Magnescale has been qualified



Traceability Flow Chart (Length)




as the calibration approval operator of "length" and magnetic scales manufactured by Magnescale are provided with traceability to the national standard.

## Installation method


### **Linear Scale SR87**

### Scale and slider installation notes

- $\cdot$  Do not turn on the power before installing the scale.
- Install the scale with the opening on the scale unit facing downward. If the opening cannot be turned downward, it should face horizontally. Never install it facing upward. (Fig. 1)
- Remove off the coating around the tap hole to ground the scale unit using the installation surface contact with the scale.
- $\cdot$  Be aware that the scale will be damaged if slider moved outside the measuring length (ML).
- In environments where coolant can splash directly on the scale, be sure to mount a cover on the scale to protect the scale from splashing. (Fig. 2)



- $\cdot$  The slider holders are used to secure the slider in place during transport.
- They are not guides for installation.
- $\cdot$  Do not take off the slider holders, if possible, until immediately before securing the slider.
- Even if the slider holders are removed, the plastic hook provided on the slider allows the slider to maintain an approximate positional relationship with the scale unit.
- The plastic hook can come off if the slider is forcibly twisted or other excessive force is applied. If the plastic hook comes off, return the plastic hook back to its original position before performing the installation. (See Fig. 4.)
- $\cdot$  After removing the slider holder, be sure to take off the clamp nuts remaining on the scale.




• Before installing the scale, check that the alignment of the installation surface (or installation brackets) is within the standards.

- Use a scale installation bracket, where applicable, having a length covering the entire scale length. The parallelism of the scale may be harmed if only using a bracket divided for the installation section.
- The foot plates on both ends and intermediate foot plate installed on the scale unit are used as the installation guides.

· Loosely turn the mounting screws first. Determine the alignment and then tighten the screws to fasten the scale. (See Fig. 5.)

Fig. 5 Scale : M6 x 35 (9 N.m)




### Installation example


Example 1 (recommended):Installation when a stop surface of the scale and slider is made with the bracket

Scale installation accuracy is improved when a stop surface is made. This also simplifies reinstallation of the scale.


 Check and adjust the scale bracket's parallelism with respect to the machine guide, and then secure in place. Even when using divided brackets, adjust the parallelism over the entire bracket length as shown in the figure.



2. Check and adjust the height and parallelism of the slider bracket, and then secure in place.



3. Bring the scale into contact with the stop surfaces and install.




### Air injection and oil lubrication

In the standard configuration, the end cap section is provided with an M5 tap hole for air injection and oil lubrication. For more detailed information, please refer to the Instruction Manual (sold separately).

### Example 2: Installation when a stop surface of the scale and slider is not made with the bracket

 Adjust the parallelism of the scale bracket and slider bracket with respect to the machine guide, and then secure in place. Adjust the height and parallelism of the slider bracket with respect to the scale bracket, and then secure in place.




 Adjust the parallelism with respect to the machine guide of the scale rear while measuring the scale rear with a dial gauge. Tighten the set screws.
 <Measurement method>

Measure near the installation hole positions at the scale unit rear.

Fig. 10

Unit: mm

3. Insert the supplied spacer (t = 1.0 mm) in the space between the scale and slider, and then adjust the slider position while bringing the slider into contact with the scale.




Please measure attachment bore position neighborhood of the main body of measurement method scale back.


### **Linear Scale SR77**

### Scale and slider installation notes

- $\cdot$  Do not turn on the power before installing the scale.
- Install the scale with the opening on the scale unit facing downward. If the opening cannot be turned downward, it should face horizontally. Never install it facing upward. (Fig. 1)
- Remove off the coating around the tap hole to ground the scale unit using the installation surface contact with the scale.
- · Be aware that the scale will be damaged if slider moved outside the measuring length (ML).
- In environments where coolant can splash directly on the scale, be sure to mount a cover on the scale to protect the scale from splashing. (Fig. 2)




- $\cdot$  The slider holders are used to secure the slider in place during transport.
- They are not guides for installation.
- · Do not take off the slider holders, if possible, until immediately before securing the slider.
- Even if the slider holders are removed, the plastic hook provided on the slider allows the slider to maintain an approximate positional relationship with the scale unit.
- The plastic hook can come off if the slider is forcibly twisted or other excessive force is applied. If the plastic hook comes off, return the plastic hook back to its original position before performing the installation. (See Fig. 4.)
- · After removing the slider holder, be sure to take off the clamp nuts remaining on the scale.



- Before installing the scale, check that the alignment of the installation surface (or installation brackets) is within the standards.
- · Use a scale installation bracket, where applicable, having a length covering the entire scale length.
- The parallelism of the scale may be harmed if only using a bracket divided for the installation section.
- The foot plates on both ends and intermediate foot plate installed on the scale unit are used as the installation guides.
- Loosely turn the mounting screws first. Determine the alignment and then tighten the screws to fasten the scale. (See Fig. 5.)

Fig. 5 Both ends : M8 x 16 (20 N.m)x.

Bring into contact




### Installation example


Example 1 (recommended):Installation when a stop surface of the scale and slider is made with the bracket

Scale installation accuracy is improved when a stop surface is made. This also simplifies reinstallation of the scale.

1. Check and adjust the scale bracket's parallelism with respect to the machine guide, and then secure in place. As shown in the figure, adjust the parallelism over the entire bracket length even when making a difference in levels on the scale installation surface.



2. Check and adjust the height and parallelism of the slider bracket, and then secure in place.



3. Bring the scale into contact with the stop surfaces and install.




Please measure it with two points that took the measurement interval widely as much as possible at a place of the same distance from the measurement method right and left scale both ends. In the case of the intermediate foot scale with, please measure the intermediate foot part.

### Air injection and oil lubrication

In the standard configuration, the end cap section is provided with an M5 tap hole for air injection and oil lubrication. For more detailed information, please refer to the Instruction Manual (sold separately).


### Example 2: Installation when a stop surface of the scale and slider is not made with the bracket

 Adjust the parallelism of the scale bracket and slider bracket with respect to the machine guide, and then secure in place. Adjust the height and parallelism of the slider bracket with respect to the scale bracket, and then secure in place.




 Adjust the parallelism with respect to the machine guide of the scale rear while measuring the scale rear with a dial gauge. Tighten the set screws.
 <Measurement method>

Measure at two points where the measurement distance is as wide as possible and at the same distance from the right and left scale ends. If using a scale with intermediate foot plate, be sure to also measure the intermediate foot plate.



Insert the supplied spacer (t = 1.0 mm) in the space between the scale and slider, and then adjust the slider position while bringing the slider into contact with the scale.

Linit<sup>,</sup> mm




### **Rotary Magnescale Installation**

### **Installation Dimensions and Tolerance**

Make preparations so that the rotary magnescale installation surface dimensions and tolerance have the values shown in the figure below.

### Installation Preparation

Transport plate is used to secure the scale unit and scale shaft so that excess vibrations are not applied to the scale shaft during transportation. Before installing the rotary magnescale, be sure to remove the transport plate.



### **Installation Precaution**

·If the surface of the rotary side or stationary side where the rotary magnescale will be installed has paint or other coating, remove the paint or coating in order to obtain conductivity between the rotary magnescale

and the machine.

Before installing the rotary magnescale, be sure to check that the dimensional tolerance of the installation surface and machine shaft are within the standards. If the installation dimensional tolerance is not within the standards, the required accuracy will not be obtained, and the rotary magnescale can even be damaged.


In environments where coolant can splash directly on the rotary magnescale, be sure to mount a cover on the rotary magnescale to protect the rotary magnescale from splashing.

•The installation nut and other installation tools must be obtained by the customer.


•The absolute position becomes 0 at the reference point mark ±2 degrees. Be sure to check its location

when securing the scale shaft. (See section 6, "Outside Dimensions.")

·In its standard configuration, the rotary magnescale has an M5 tap hole for air injection.



Note The transport plate does not set the installation standard for the rotary magnescale. Perform the installation by following section 5-1, "Installation Dimensions and Tolerance."



### Installation Procedure

- 1. Check that there is no dust or scratches on the rotary magnescale installation surface. Check that there are no indentations, rust, or scratches on the machine shaft where the rotary magnescale will be installed. Completely wipe off any dust and dirt on the machine shaft.
- 2. Insert the rotary magnescale gently into the machine shaft. The machine shaft and scale shaft are designed for a precise fit, and so do not try to force insertion of the rotary magnescale into the machine shaft.
- 3. Secure the rotary magnescale.

Use M4 screws to install from the rotary magnescale top, and use M6 screws to install from the rotary magnescale bottom. (M4 tightening torque: 2.5 N.m)

4. Use the installation nut to secure the scale shaft to the machine shaft.


(M20 x 1 tightening torque: 20 N.m)


The securing operation can be performed more smoothly by using a tightening wrench and fastening wrench as shown in the "7. Appendix."

## **Mechanical Specifications**

### Air purging

If Magnescale is used in a dusty or misty environment, it is recommended that air is introduced into the scale to alleviate any unwanted effects. Attach air nipples to M5 holes for air introduction that are provided at both ends of the scale to supply air into the scale. When introducing air into the scale, supply air via an air filter (nominal filtration rating: 5 µm), mist separator (nominal filtration rating: 0.3 µm), and a regulator to remove dust, dirt, and mist. As a guide, the amount of air supplied to the scale is 30 NL/min.





M5 × 6 hex. socket head screw

## **SR87**

This robust type magnetic absolute scale system that outputs position signals for machine tools and other equipment that require high-precision positioning.

Measuring Length(ML): 140-3,040mm
• Accuracy : 3+3ML/1,000 µm p-p,
5+5ML/1,000 µm p-p

- Maximum resolution : 0.01 µm
- Maximum response speed : 200m/min.
- Protocol : FANUC, Mitsubishi,

Panasonic, YASKAWA

ABS	Robust type	Maximum resolution 0.01 µm	
-----	----------------	----------------------------------	--

### **Specifications**


Model	
Measuring length (ML)	140, 240, 340, 440, 540, 640, 740, 840, 94 2040, 224
Thermal expansion coefficient (/ °C)	
Output signal	Absolute serial bidire
Accuracy (at 20 °C) ML:mm	3+3ML/1,000 µ
Resolution	Selectable from 0.01,0.05,
Zero count position	
Power supply voltage	DC4.75 - 5.2
Consumption current	200 mA
Imrush current	2A max. (When th
Maximum response speed	200m/min (Us
Vibration resistance	25
Impact resistance	
Protective design grade	IP54 (Air purge not
Other protections	Oil lubricant can also be us
Power supply protection	In the case of errors such as a r the internal fuse is cut to p
Safety standards	FCC Part15 Subpart B 0 EN55011 Gp1 Class A, EN61000-6
Operating temperature range( °C)	
Storage temperature range( °C)	
Mass	Арр

Slider sliding resistance


Model	CH33-**CP	
Description	Cable with open end	C
Cable length	3,5,10	0,15m
Material	PVC	
Armor	YES	

\*Please consult with our sales for the cable length other than above.

### **Details of model designation**



\* When the slider is moved in the direction of the arrow, the signal is addition when the direction is "positive," and it is subtraction when the direction is "negative." The direction is selected when ordering





140~3040mm 940, 1040, 1140, 1240, 1340, 1440, 1540, 1640, 1740, 1840, 240, 2440, 2640, 2840, 3040

12 ± 1	x 10 <sup>-6</sup> / °C	

ectional signal, compliant with EIA-485

μm p-p or 5+5ML/1,000 μm p-p

,0.1,0.5 and 1.0 μm( Set at factory shipping)

Center mark

25V(At cable connection end)

(at 120  $\Omega$  terminal) max.

ne power supply rise time is 10 ms)

ser-selected resolution setting)

0m/s<sup>2</sup> (50Hz~2kHz)

450m/s<sup>2</sup> (11ms)

included), IP65 (Air purge included)

sed under severe environmental conditions.

reverse-connected power supply or over-voltage. protect the power being supplied and wiring.

Class A. ICES-003 Class A Digital Device.

6-2. Safety standards not applicable (60 V DC or less).

0 ~ +50 °C

-20 ~ +55 °C

prox.1.24kg + 4kg/m

1N or less

Cable with open end

PU YES

9mm E	1,800~1,899mm J
9mm F	1,900~1,999mm K
99mm G	2,000~2,040mm L
0mm H	$E_{x:1}$ 050mm $\rightarrow$ 450

NC Maker	Wire	
FANUC	4	Α
Mitsubishi	2	В
WIIISUDISIII	4	D
YASKAWA	2	F
Panasonic	2	Н

Resolution	Direc	tion
(µm)	+	-
0.01	Α	F
0.05	В	G
0.1	С	Н
0.5	D	J
1.0	Е	Κ
YASK	AWA	
Number of	Direc	tion
Divisions	+	-
1/8192	L	-
1/1024	Μ	-
Note:Mits	ubisł	ni co

controler is only A





NUL 

March 140 

| | | | | | | | | |

nit 32 33 36 44 22 20 19 18





Unit : mm

19±0.1

5±0.2

Dimensions SR87 Cable Direction Left

 1478

 1578

 1678

 1678

 1778

 1778

 2378

 2378

 2378

 2378

 2378

 2378

 2378

 2378

 2378

 2378

 2378

 2378

 2378


 2378

 2378

 2378

MI ML : Meɛ // 0.1 MG

0.05



Magnescale.

## SR84/85

This robust medium type magnetic scale system that outputs position signals for machine tools and other equipment that require high-precision positioning.

•	Measuring	l enath(l	MI):1	40-3	040mm

• Accuracy : 3+3ML/1,000 µm p-p,

III .

- 5+5ML/1,000 µm p-p
- Maximum resolution : 0.01 µm
- Maximum response speed : 200m/min.
- Protocol (SR85) : Mitsubishi


Robust type	Maximum resolution 0.01 μm
	(SR85 only)

### **Specifications**

Mea

del	SR84			SR85			
asuring length (ML)	140~3040mm 140, 240, 340, 440, 540, 640, 740, 840, 940, 1040, 1140, 1240, 1340, 1440, 1540, 1640, 1740, 1840, 2040, 2240, 2440, 2640, 2840, 3040						
ermal expansion coefficient (/ °C	12 ± 1 x 10 <sup>-6</sup> / °C						
tput signal		A/B, Reference point line driver signal Increme (compliant with EIA-422)					
curacy (at 20 °C) ML:mm		3+3ML/1,000 µm p-p o	r 5+5ML/1,000 μr	n p-p			
solution		Selectable from 0.05,0.1,0.5 and 1.0 µm Selectable (Set at factory shipping) (					
ference point	None, Center point, Multi-poir Reference mark (standard p User-selected point (1	None, Center point, er-selected point (1 mm pitch)					
wer supply voltage		DC4.75 - 5.25V(At ca	able connection e	nd)			
nsumption current		200 mA (at 120 s	Ω terminal) max.				
ush current	2A	max. (When the power	supply rise time i	s 10 ms)			
ximum response speed	50m/min(Resolution: Minimum phase differenc	(Us	200m/min er-selected resolution setting)				
ration resistance		250m/s² (5	0Hz~2kHz)				
oact resistance		450m/s <sup>2</sup>	2 (11ms)				
tective design grade	IP54	(Air purge not included	d), IP65 (Air purge	included)			
ner protections	Oil lubricant	can also be used unde	er severe environn	nental conditions.			
wer supply protection		ors such as a reverse-c fuse is cut to protect th					
fety standards		15 Subpart B Class A. I A, EN61000-6-2. Safety		Digital Device. oplicable (60 V DC or less).			
erating temperature range(°C	;)	0 ~ +	50 °C				
rage temperature range( °C)		-20 ~ -	+55 °C				
SS		Approx.1.24	-kg + 4kg/m				
ler sliding resistance		1N or	rless				
odel	CH33-**CP	CH33-**0	E				
escription	Cable with open end	Cable with op	en end				
able length	3,5,10	),15m					
aterial	PVC	PU					
mor	YES	YES					
ase consult with our sales for	r the cable length other than above.						
tails of model d	lesignation ———			Disess			
84-×××★○△◆ 85-×××★○△■	850mm = 850, in case of left digits shown by alph           1         1,000-1,099mm A 1,           1,100-1,199mm B 1,           1,200-1,299mm C 1,	400~1,499mm E 1,80 500~1,599mm F 1,90 600~1,699mm G 2,00	end of ML e.g.	Phase (ns)         Phase           50         A         500         H           100         B         650         J           150         C         1000         K           200         D         1250         L           250         E         2500         M           300         F         3000         N           400         G         G         G			

Thermal expansion coefficient (/ °C)	10 <sup>-6</sup> / °C						
Output signal	A/B, Reference point line (compliant with EIA	Incremental serial bidirectional signal, compliant with EIA-485					
Accuracy (at 20 °C) ML:mm	3+3ML/1,000 μm p-p or 5+5ML/1,000 μm p-p						
Resolution	Selectable from 0.05,0.1,0 ( Set at factory ship	•	Selectable from 0.01,0.05,0.1,0.5 and 1.0 μm ( Set at factory shipping)				
Reference point	None, Center point, Multi-poi Reference mark (standard j User-selected point (1	None, Center point, User-selected point (1 mm pitch)					
Power supply voltage		DC4.75 - 5.25V(At ca	able connection end)				
Consumption current		200 mA (at 120	$\Omega$ terminal) max.				
Imrush current	2A	max. (When the power	supply rise time is 10 ms)				
Maximum response speed	50m/min(Resolution: 0.1 um,     200m/min       Minimum phase difference: at 50 ns)     (User-selected resolution set						
Vibration resistance		250m/s² (5	0Hz~2kHz)				
Impact resistance	450m/s² (11ms)						
Protective design grade	IP54 (Air purge not included), IP65 (Air purge included)						
Other protections	Oil lubricant can also be used under severe environmental conditions.						
Power supply protection	In the case of errors such as a reverse-connected power supply or over-voltage, the internal fuse is cut to protect the power being supplied and wiring.						
Safety standards			CES-003 Class A Digital Device. / standards not applicable (60 V DC or less).				
Operating temperature range( °C)		0 ~ +	50 °C				
Storage temperature range( °C)		-20 ~	+55 ℃				
Mass		Approx.1.24	kg + 4kg/m				
Slider sliding resistance		1N o	rless				
Model	CH33-**CP	CH33-**0	CE				
Description	Cable with open end	Cable with op	en end				
Cable length	3,5,10	),15m					
Material	PVC						
Armor	YES YES						
Armor Please consult with our sales for the	-	YES					
Details of model de	signation ———						
SR84-X X X ★ O △ ♦ □ SR85-X X X ★ O △ ■ □	1         1         850mm = 850, in case of left digits shown by alph           1         1,000-1,099mm A 1,           1,100-1,199mm B 1,	400~1,499mm E 1,80	end of ML e.g.				




### Magnescale


	Resolution	esolution SR84		SR85	
	(µm)	+	-	+	-
)µm	0.01	-	-	Α	F
	0.05	В	G	В	G
	0.1	С	Н	С	Н
	0.5	D	J	D	J
	1.0	Е	К	E	K


NC Maker Wire 2 Mitsubishi

When the slider is moved in the direction of the arrow, the A signal is ahead when the direction is "positive," and B signal is ahead when the direction is "negative."









Unit : mm


Dimensions SR84/85 Cable Direction Left

||||||

MI MML: Mec

// 0.1 MG

0.05



Magnescale.

## **SR77**

This slim type magnetic scale system that outputs position signals for machine tools and other equipment that require high-precision positioning.

TI

<ul> <li>Measuring Length(ML) : 70-2,040mm</li> </ul>
---

- Accuracy : 3+3ML/1,000 μm p-p,
  - 5+5ML/1,000 µm p-p
- Maximum resolution : 0.01 µm
- Maximum response speed : 200m/min.
- Protocol : FANUC, Mitsubishi,

Panasonic, YASKAWA

ABS	Slim type	Maximum resolution 0.01 µm	
-----	--------------	----------------------------------	--


### **Specifications**

Measuring length (ML)	70, 120, 170, 220, 270, 320, 370, 4 1240, 1340, 14
Thermal expansion coefficient (/ °C)	
Output signal	Absolute serial bidir
Accuracy (at 20 °C) ML:mm	3+3ML/1,000
Resolution	Selectable from 0.01,0.05
Zero count position	
Power supply voltage	DC4.75 - 5
Consumption current	200 m/
Imrush current	2A max. (When t
Maximum response speed	200m/min (L
Vibration resistance	1
Impact resistance	
Protective design grade	IP54 (Air purge no
Other protections	Oil lubricant can also be
Power supply protection	In the case of errors such as a the internal fuse is cut to
Safety standards	FCC Part15 Subpart B EN55011 Gp1 Class A, EN61000-
Operating temperature range( °C)	
Storage temperature range( °C)	
Mass	App
Slider sliding resistance	


Model	CH33-**CP	
Description	Cable with open end	
Cable length	3,5,1	0,15m
Material	PVC	
Armor	YES	

\*Please consult with our sales for the cable length other than above.

### Details of model designation



\* When the slider is moved in the direction of the arrow, the signal is addition when the direction is "positive," and it is subtraction when the direction is "negative." The direction is selected when ordering.





70~2040mm

420, 470, 520, 570, 620, 720, 770, 820, 920, 1020, 1140, 1440, 1540, 1640, 1740, 1840, 2040

12	±	1	х	10	6/	°C
----	---	---	---	----	----	----

irectional signal, compliant with EIA-485

μm p-p or 5+5ML/1,000 μm p-p

5,0.1,0.5 and 1.0 µm( Set at factory shipping)

Center mark

5.25V(At cable connection end)

nA (at 120 W terminal) max.

the power supply rise time is 10 ms)

User-selected resolution setting)

150m/s<sup>2</sup> (50Hz~3kHz)

350m/s<sup>2</sup> (11ms)

ot included), IP65 (Air purge included)

used under severe environmental conditions.

reverse-connected power supply or over-voltage, protect the power being supplied and wiring.

3 Class A. ICES-003 Class A Digital Device.

-6-2. Safety standards not applicable (60 V DC or less).

0 ~ +50 °C

-20 ~ +55 °C

prox.0.27kg + 1.36kg/m

1N or less

Cable with open end

PU

YES

99mm	E	1,800~1,899mm J
99mm	F	1,900~1,999mm K
99mm	G	2,000~2,040mm L
'99mm	н	Ex:1,050mm → A50

NC Maker	Wire	
FANUC	4	Α
Mitsubishi	2	В
MILSUDISHI	4	D
YASKAWA	2	F
Panasonic	2	Н


0.01         A         F           0.05         B         G           0.1         C         H           0.5         D         J           1.0         E         K           YASKAWA         Number of Divisions + -         Direction Obvisions + -           1/8192         L         -		FANUC, M Panas				
0.01 A F 0.05 B G 0.1 C H 0.5 D J 1.0 E K YASKAWA Number of Divisions + - 1/8192 L -		Resolution	Direc	tion		
0.05         B         G           0.1         C         H           0.5         D         J           1.0         E         K           YASKAWA           Number         Direction Divisions         H           1/8192         L         -	n	(µm)	+	-		
0.1         C         H           0.5         D         J           1.0         E         K           YASKAWA           Number Direction of Divisions         H           1/8192         L		0.01	Α	F		
0.5         D         J           1.0         E         K           YASKAWA         Number         Direction           Number         Direction         Divisions           1/8192         L         -		0.05	В	G		
1.0         E         K           YASKAWA         Number         Direction           Divisions         +         -           1/8192         L         -		0.1	С	Н		
YASKAWA Number Of Divisions + - 1/8192 L -		0.5	D	J		
Number of DivisionsDirection1/8192L-		1.0	Е	Κ		
of Divisions + - 1/8192 L -		YASK	AWA			
Divisions + - 1/8192 L -			Direc	tion		
			+	-		
1/1024 M -		1/8192	L	-		
		1/1024	Μ	-		

Note:Mitsubishi controler is only A

**Dimensions SR77** Cable Direction Right

ML	2	<u>۳</u>	L4	L5	c	ML	5	2	<u>ت</u>	4	L5	5
70 208	185	ı	ı	ı	0	770	908	885	442.5	ı	442.5	
120 258	235	I	ı	I	0	820	958	935	467.5	I	467.5	-
170 308	285	ı	ı	ı	0	920	1058	1035	517.5	I	517.5	-
220 358	335	ı	1	ı	0	1020	1158	1135	567.5	ı	567.5	-
270 408	385	I	I	I	0	1140	1278	1255	627.5	I	627.5	-
320 458	435	ı	ı	ı	0	1240	1378	1355	677.5	ı	677.5	-
370 508	485	ı	ı	ı	0	1340	1478	1455	727.5	I	727.5	-
420 558	535	ı	1	1	0	1440	1578	1555	520	520	515	2
470 608	585	I	ı	I	0	1540	1678	1655	550	550	555	2
520 658	635	ı	ı	ı	0	1640	1778	1755	585	585	585	2
570 708	685	ı	ı	ı	0	1740	1878	1855	620	620	615	5
620 758	735	ı	ı	ı	0	1840	1978	1955	650	650	655	2
720 858	835	417.5	ı	417.5	-	2040	2178	2155	720	720	715	2
ML : Measuring length CL : Cable length MG: Machine guide	gth CL:	Cable ler	ngth MG.	: Machine	e guide							Jnit : mm

when ML > 1440 i 720 ₹



Unit :


																						9)	
																					L5	}	
																		L1=ML+138	1 2=M1 +115		L4	(MIL)	n × 04.5 Manutic comman 44.4.10
L5 n	442.5 1	467.5 1	517.5 1	567.5 1	627.5 1	677.5 1	727.5 1	15 2	555 2	585 2	615 2	655 2	715 2	Unit : mm									n × Intermediate foot plate
L4	- 44.	- 46	- 513	- 56	- 62	- 67	- 72		550 5		620 6				ш						L3	,	7.5
3	442.5	467.5	517.5	567.5	627.5	677.5	727.5			585			720		- > 1440 n								•
2		-	1035		1255	-		1555	1655	1755	1855	1955	2155		s when MI	edepth 9	3×16)					73	
5	908	958	1058	1158	1278	1378	1478	1578	1678			1978	2178		o locations	Sinkhole	crews M8						
۶	770	820	920	1020	1140	1240	1340	1440	1540	1640	1740	1840	2040		im and two	2 – ø10 ø15 Sinkhole depth 9	(Mounting screws M8×16)	1	11.5			<u></u>	
-	0	0	0	0	0	0	0	0	0	0	0	0	-	guide	AL > 720 n	2	Ŵ	/	_	_			3.
2	I	ı	ı	I	I	1	ı	ı	ı	ı	ı	I	417.5	Machine (	on when N							ir pu	rge
4	I	1	1	ı	I		1	1	1	1	1	I	1	ngth MG:	one locatic			(1	VI5 :	: В	otř	9.2	a)
5	I	ı	ı	I	I	1	ı	ı	ı	ı	ı	I	417.5	ML: Measuring length CL: Cable length MG: Machine guide	* Intermediate foot plate: Installed in one location when ML > 720 mm and two locations when ML > 1440 mm							<u>¥</u>	
1	185	235	285	335	385	435	485	535	585	635	685	735	835	ingth CL:	it plate: In:								7
2			.			<u>_</u>	6	œ	8	658	708	758	858	ing le	te foo				[	11	0.	.1	MG
5		258	308	358	408	458	508	558	608	99	~	75	œ	asur	edia								

(65)

φ

**Dimensions SR77** 

Cable Direction Left



Magnescale.

Unit : mm

## SR74/75

This slim type magnetic scale system that outputs position signals for machine tools and other equipment that require high-precision positioning.

171

•	Measuring	Length(ML) : 70-2,040mm
	Accuracy :	$3+3MI / 1 000 \mu m n - n$

- 5+5ML/1,000 µm p-p
- Maximum resolution : 0.01 µm
- Maximum response speed : 200m/min.
- Protocol (SR75) : Mitsubishi


Slim ype	Maximum resolutior 0.01 µm
	(SR75 only)

### **Specifications**

SR74	
70, 120, 170, 22 1020, 1	0, 270, 32 140, 1240
3)	
A/B, Reference point line (compliant with EIA	-
	3+3ML/1,
Selectable from 0.05,0.1,0 ( Set at factory ship	
None, Center point, Multi-poi Reference mark (standard p User-selected point (1	pitch: 20 n
	DC4.75
	20
2A	max. (Wh
50m/min(Resolution: Minimum phase difference	
IP54	4 (Air purg
Oil lubricant	t can also
In the case of err the internal	
FCC Part EN55011 Gp1 Class	15 Subpa A, EN610
2)	
CH33-**CP	
	70, 120, 170, 22 1020, 1 A/B, Reference point line (compliant with El/ Selectable from 0.05, 0.1,0 (Set at factory ship None, Center point, Multi-poi Reference mark (standard ) User-selected point (1 2A 50m/min(Resolution: Minimum phase differenc IP54 Oil lubricant In the case of err the internal FCC Part EN55011 Gp1 Class C)

Thermal expansion coefficient (/ °C	5)	12 ± 1 x	10"% °C										
Output signal	A/B, Reference point line (compliant with El/	0		l serial bidirectional signal, pliant with EIA-485									
Accuracy (at 20 °C) ML:mm		3+3ML/1,000 µm p-p c	r 5+5ML/1,000 μm p-p										
Resolution	Selectable from 0.05,0.1,0 ( Set at factory shi			n 0.01,0.05,0.1,0.5 and 1.0 μm at factory shipping)									
Reference point	None, Center point, Multi-poi Reference mark (standard User-selected point (1	pitch: 20 mm),		one, Center point, acted point (1 mm pitch)									
Power supply voltage		DC4.75 - 5.25V(At ca	able connection end)										
Consumption current		200 mA (at 120	$\Omega$ terminal) max.										
Imrush current	2A	A max. (When the power	supply rise time is 10 n	ns)									
Maximum response speed	50m/min(Resolution: Minimum phase differenc		(User-sel	200m/min lected resolution setting)									
Vibration resistance		150m/s² (5	0Hz~3kHz)										
Impact resistance		350m/s	² (11ms)										
Protective design grade	IP54	4 (Air purge not included	d), IP65 (Air purge includ	ded)									
Other protections	Oil lubrican	t can also be used unde	er severe environmental	conditions.									
Power supply protection		rors such as a reverse-c fuse is cut to protect th											
Safety standards		t15 Subpart B Class A. A, EN61000-6-2. Safet	-										
Operating temperature range( °C	C)	0 ~ +	50 °C										
Storage temperature range( °C)		-20 ~	+55 ℃										
Mass	Approx.0.27kg + 1.36kg/m 1N or less												
Slider sliding resistance													
Model	CH33-**CP	CH33-**0	E										
Description	Cable with open end	Cable with op	en end										
Cable length	3,5,10	0,15m											
Material	PVC	PU											
Armor	YES	YES											
Please consult with our sales for	r the cable length other than above.												
Details of model of	designation ———												
Γ		Minimum phase differe	nce	Phase difference (ns)									
SR74-×××★○△◆		(ns)         500         A         500         H           100         B         650         J           150         C         1000         K           200         D         1250         L           250         E         2500         M           300         F         3000         N           400         G         G         G											
	Communication protocol			NC Maker Wire									
	Resolution & Direction*	Mitsubishi 4 D											
	- Accuracy grade A : 5+5ML/1000 S : 3+3												
	ML : Measuring length by mm - Cable out direction: R= Right, L= Left												

### D



¢ <b></b>	* When the slider is moved the direction is "positive,"
	,,,,,,,,-
$\rightarrow$	



70~2040mm


20, 370, 420, 470, 520, 570, 620, 720, 770, 820, 920, 0, 1340, 1440, 1540, 1640, 1740, 1840, 2040

d in the direction of the arrow, the A signal is ahead when "and B signal is ahead when the direction is "negative."

Dimensions SR74/75 Cable Direction Right


c	-	-	-	-	-	-	-	5	2	2	5	0	2	Jnit : mm	
L5	442.5	467.5	517.5	567.5	627.5	677.5	727.5	515	555	585	615	655	715		
L4	I	I	I	I	I	I	I	520	550	585	620	650	720		
L3	442.5	467.5	517.5	567.5	627.5	677.5	727.5	520	550	585	620	650	720		11 - 1 A A
L2	885	935	1035	1135	1255	1355	1455	1555	1655	1755	1855	1955	2155		- and more
Ц	908	958	1058	1158	1278	1378	1478	1578	1678	1778	1878	1978	2178		
ML	770	820	920	1020	1140	1240	1340	1440	1540	1640	1740	1840	2040		nt puo mu
c	0	0	0	0	0	0	0	0	0	0	0	0	-	guide	latormodiate foot alato: lactollod in one location when MI > 700 mm and two locations when MI > 1110 mm
L5	1	ı	ı	ı	1	ı	ı	1	1	ı	1	ı	417.5	Machine	l acdue ac
L4	1	ı	ı	ı	1	ı	ı	ı	ı	ı	1	ı	ı	igth MG:	itoooti
L3	ı	I	I	ı	ı	I	I	ı	ı	I	ı	I	417.5	ML: Measuring length CL: Cable length MG: Machine guide	tollog
L2	185	235	285	335	385	435	485	535	585	635	685	735	835	ngth CL:	alato: lac
L1	208	258	308	358	408	458	508	558	608	658	708	758	858	tsuring let	dinto foot
ML	20	120	170	220	270	320	370	420	470	520	570	620	720	ML : Mea	*






E Unit : r


[	Di	m	ne	ns	sic	on	s	S	R	74	/7	′5							1						ł	
(	Ca	bl	e	Dir	rec	tic	on	Le	eft												1				╞	
																								(65)		
																								9)		
																						2				
																						_	1		ł	
																							ł			(
																										× 10)
																						14				n × ø4.5 (Mounting screw M4 × 10)
																			8		2	-	1			lg scr
																			L1=ML+138		L2=ML+115			(ML)		n × ø4.5 (Mountin
																			L1=^		L2 					c C
																							ł		t	
																										diate
																										n × Intermediate foot plate
	c		-	-			-	-	5	5	5	2	2	5	Unit : mm											<u>n × Interm</u> foot plate
	10	5	5.	5.	5.	5.	5.	5.	5	55	585	615	55	5	Cnit											
	L5	442.5	467.5	517.5	567.5	627.5	677.5	727.5														er. 	3			7.5
	۲4	1	1	1	1	1	1	1		550		620		720		140 mm									ł	
	2	442.5	467.5	517.5	567.5	627.5	677.5	727.5	520	550	585	620	650	720		ML > 1440 mm	6 (	I								
	2	885	935	1035	1135	1255	1355	1455	1555	1655	1755	1855	1955	2155		ns when	2 - ø10 ø15 Sinkhole depth 9	18×16)						73		
	5	908	958	1058	1158	1278	1378	1478	1578	1678	1778	1878	1978	2178		o locatio	Sinkhol	(Mounting screws M8×16)								
	ML	770	820	920	1020	1140	1240	1340	1440	1540	1640	1740	1840	2040		and two	10 ø15	nting sc		L	0	<u>/</u>	¥			
																720 mm	9 1 1	(Moul		_	_	/	-	~	Ł	
	c	0	0	0	0	0	0	0	0	0	0	0	0	-	ne guide	- ML										3.5
	L5	ı	ı	1	1	ı	ı	1	ı	ı	ı	ı	I	417.5	Machin	on whei						for a Bot				
	۲4	ı	1			1	1		1	ı	1	1	ı	ı	th MG:	e locati.			(I	VIU		000		9.17.0	(u)	1.6
	2	1	1			1	1		1	1	1	1	1	417.5	ble leng	ed in on							1	Ę	<b>ග</b>	
		185	35	285	35	385	435	485	535	585	35	685	735	835 4-	CL : Ca	te: Install										003
		_		-	$\vdash$	$\vdash$	-	508 48	$\vdash$		658 63		_	858 83	ML : Measuring length CL : Cable length MG: Machine guide	* Intermediate foot plate: Installed in one location when ML > 720 mm and two locations when					/	// (	).'	1	N	1G
	-	_		-	$\vdash$										Measuri	rmediat					ſ	7.1	<u> </u>	4		
	M	20	120	170	220	270	320	370	42C	470	520	570	620	720	ML:I	* Intei					[	//	0	.1	1	MG












Unit : mm/inch

SL331 Specifications	
Model	SL331-20 to SL331-800
Effective length L mm (inch)	200/300/400/500/600/700/800/1000/1200/1500/1600/1700/1800/2000/2500/3000/4000/5000/6000/7000/8000 (7.8/11.8/15.7/19.6/23.6/27.5/31.4/39.3/47.2/59.0/62.9/66.9/70.8/78.7/98.4/118.1/157.4/196.8/236.2/275.5/314.9)
Overall length	L +100 mm/ 3.9*
Accuracy (20 °C /68 °F)	(15 + 5L/1000) μm
Resolution	5 μm
Max. response speed	Varies with the resolution
Expansion coefficient	$(10.4 \pm 1) + 10^{-6}$ °C
Operating temperature	-5 °C to 45 °C / 23 °F to 113 °F
Storage temperature	-10 °C to 50 °C / 14 °F to 122 °F
Compatible read head	PL60

PL60 Specifications	
Model	PL60-3
Head clearance	Max.0.8 mm/ 0.031" (no contact)
Protective design grade	Equivalent to IP65
Operating temperature	-5 °C to 45 °C / 23 °F to 113 °F
Storage temperature	-10 °C to 50 °C / 14 °F to 122 °F
Read head cable length	3 m/ 9.8'
Compatible scale	SL331
Compatible interpolator	MJ100/ 110
Extension cable (option)	CE08-011m,CE08-033m,CE08-055m, CE08-1010m,CE08-1515m


\*Cable length of more than 15m,Please consalt our sales.

### Response speed of PL60






S		_			1 0/S ection and a lor			0	gnescale <b>D</b>	igiruler。
Resistant to ( Resolution: 1 Max. respons Available in le High cost effi of machines	istance t oil, dirt, γ 0 μm se speed engths u iciency. from wo	to workshop corvibration, and sh vibration, and sh d: 300 m/ min (v p to 30 m (SL13 Easy installation bod working to n	nock. aries with the 30) on all types netal cutting.	read head a	nd settings).	SL13			1	
Scale SL110/130	-	Headcable         C           81/82         PL25         C	Cable E08 CK-T12/13/14/15/16	Interpo MJ100/			SL110			
Dimensions										
SL110	-	(♣) (♣) 4.1/0.161×6/0.23 ×300/11.81 ▲ Measuring length (↓)	6 oval P1 Clamp p1 finclude	10.5/0.41 ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓	← SL130	<ul> <li>50/ 1.97 →</li> <li>50/ 1.97 →</li> <li>4</li> <li>1</li> <li>4</li> <li>0.16)</li> </ul>	Measurin	ig length (L)	<b>50/ 1.97</b> <b>→ → → → → → → → → →</b>	
	<b>*</b>	verall length : L + 103/ 4.		10.5/0.41		Model name           SL130-20           SL130-30           SL130-40           SL130-50           SL130-60	Effective length 200 300 400 500 600	Movable length           230           330           430           530           630	Overall length 300 400 500 600 700	
Model name	Effective I	ength N	P1	Number of Clar	nps	SL130-70 SL130-80	700 800	730 830	800 900	
SL110-20	200	0	200	4		SL130-100	1000	1030	1100	
SL110-30	300		0	4		SL130-120 SL130-150	1200	1230	1300	
SL110-40 SL110-50	400 500		200	6		SL130-150 SL130-160	1500	1530 1630	1600 1700	
SL110-60	600		0	6		SL130-170	1700	1730	1800	
SL110-70	700	2	100	8		SL130-180	1800	1830	1900	
SL110-80	800		200	8	_	SL130-200	2000	2030	2100	
SL110-100 SL110-120	1000		0	10		SL130-250 SL130-300	2500 3000	2530 3030	2600 3100	
SL110-120	1200		0	12		SL130-300	4000	4030	4100	
SL110-160	1600	) 5	100	14		SL130-500	5000	5030	5100	
SL110-170	1700		200	14		SL130-600	6000	6030	6100	
SL110-180 SL110-200	1800		200	14		SL130-700 SL130-800	7000 8000	7030 8030	7100 8100	
02110 200	2000		200	10		3E130-000	0000	0000	0100	Unit : mm/inch
SL110/130 Sp	ecificati	ions								
Model			SL110				SL130			
			-20 to -200		-20 t	o -700			-800 to -3000	
Effective length L mm (inch)		1500/1 (7.8/11.8/15.7/1	00/600/700/800/10 600/1700/1800/200 9.6/23.6/27.5/31.4/ 52.9/66.9/70.8/78.7)	0 39.3/47.2/	(7.8/11.8/15.7/19.6 47.2/59.0/62.9/66.9/	800/2000/2500/30 0/6000/7000 /23.6/27.5/31.4/3	9.3/		0/10000/20000/3 1.3/393.7/787.4/1	
Overall length         L+103 mm/4.1*         L+100 mm/3.9*           Accuracy         (50 + 10L/1000 + 20N) µm L : Measuring length(mm)										
(20 °C /68 °F) (50 + 10L/ 1000) μm N=1 when L=8000/9000/10000 , N=2 when L=20000 , N=3 when L=30000										
Resolution Max. response spee	d					μm m/ min				
Expansion coefficien										
-	perating temperature         -5 °C to 45 °C / 23 °F to 113 °F									
Storage temperature						/ 14 °F to 122 °F				
Compatible read hea	ad				PL20	)B/ 25				
Compatible read head and Interpolate	or				PL81/3	32 Series				
Accuracy shows the va	alue when us	sed with PL20B/25 read	head and PL81/82.							



Model name	Effective length	N	P1	Number of Clamps
SL110-20	200	0	200	4
SL110-30	300	1	0	4
SL110-40	400	1	100	6
SL110-50	500	1	200	6
SL110-60	600	2	0	6
SL110-70	700	2	100	8
SL110-80	800	2	200	8
SL110-100	1000	3	100	10
SL110-120	1200	4	0	10
SL110-150	1500	5	0	12
SL110-160	1600	5	100	14
SL110-170	1700	5	200	14
SL110-180	1800	6	0	14
SL110-200	2000	6	200	16

SL	-			10/SL <sup>2</sup>		-		giruler。	
<ul> <li>Magnetic principle</li> <li>Excellent resistance to Resistant to oil, dirt, vi</li> <li>Resolution: 10 µm</li> <li>Max. response speed</li> <li>Available in lengths up</li> <li>High cost efficiency. E of machines from wood</li> </ul>	bration, and sho 300 m/ min (var to 30 m (SL130 asy installation o	ck. ries with the r ) n all types			0		1		
	eadcable 1/82 PL25 CE08	Cable CK-T12/13/14/15/16	Interpolat MJ100/11		SL110				
Dimensions									
SL110	4.1/0.161 x 6/0.236 c 300/ 11.81 P1 Measuring length (L)		10.5/0.41	SL130	Measuri	ng length (L)	50/ 1.97		
	erall length : L + 103/ 4.06				Effective length	Movable length	Overall length		
			14	SL130-20	200	230	300		
			5/0.41	SL130-30 SL130-40	300 400	330 430	400		
			10.	SL130-50	500	530	600		
				SL130-60	600	630	700		
			I	SL130-70	700	730	800		
Model name Effective ler	-	P1	Number of Clamp		800	830	900		
SL110-20 200	0	200	4	SL130-100	1000	1030	1100		
SL110-30 300	1	0	4	SL130-120	1200	1230	1300		
SL110-40 400	1	100	6	SL130-150	1500	1530	1600		
SL110-50 500	1	200	6	SL130-160	1600	1630	1700		
SL110-60 600	2	0	6	SL130-170	1700	1730	1800		
SL110-70 700	2	100	8	SL130-180	1800	1830	1900		
SL110-80 800	2	200	8	SL130-200	2000	2030	2100		
SL110-100 1000	3	100	10	SL130-250	2500	2530	2600		
SL110-120 1200	4	0	10	SL130-300	3000	3030	3100		
SL110-150 1500	5	0	12	SL130-400	4000	4030	4100		
SL110-160 1600	5	100	14	SL130-500	5000	5030	5100		
SL110-170 1700	5	200	14	SL130-600	6000	6030	6100		
SL110-180 1800	6	0	14	SL130-700	7000	7030	7100		
SL110-200 2000	6	200	16	SL130-800	8000	8030	8100	Unit : mm/inch	
SL110/130 Specificatio	ons								
		SL110			SL130	)			
Model		20 to -200		-20 to -700			-800 to -3000		
		2010 200			000/				
Effective length L mm (inch)	/600/700/800/100 0/1700/1800/2000 5/23.6/27.5/31.4/3 9/66.9/70.8/78.7)	D	200/300/400/500/600/700/800/100/1 1500/1600/1700/1800/200/2500/30 4000/5000/6000/7000 (7.8/11.8/15.7/19.6/23.6/27.5/31.4/3 47.2/59.0/62.9/66.3/70.8/78.7/8.4/1 157.4/196.8/236.2/275.5)	00/ 9.3/	8000/9000/10000/20000/30000 (314.9/354.3/393.7/787.4/1181.1)				
Overall length	L+1	03 mm/ 4.1"			L+100 mm	/ 3.9"			
Accuracy (20 °C /68 °F)			(50 + 10L/ 10	00) μm			:0N) μm L : Meası L=8000/9000/100 20000 , N=3 when	000,	
Resolution 10 µm									
Max. response speed 300 m/ min									
Expansion coefficient									
Operating temperature				-5 °C to 45 °C / 23 °F to 113 °F					
	temperature -10 °C to 50 °C / 14 °F to 122 °F								
Storage temperature									
				PL20B/ 25					



\*For cable lengths greater than 15 meters, please contact our sales office.


PL81/PL82

- Compact design
- Interpolator unit for automated position control
- High response speed: 300 m/mim

27/1.06

• Resolution: 10 μm, 20 μm, 25 μm, 50 μm, 100 μm

E	Example for connection					
	Scale					
	SL110/130		PL81/82			
1						
	Dimonolono					



Specifications										
			PL81					PL82		
Model	-3	-5	-7	-A	-B	-3	-5	-7	-A	-B
Cable length (inch)	3m (118.1)	5m (196.9)	7m (275.6)	10m (393.7)	15m (590.6)	3m (118.1)	5m (196.9)	7m (275.6)	10m (393.7)	15m (590.6
Mass (g)	640	720	800	910	1050	640	720	800	910	1050
Accuracy (20 °C / 68 °F)		(50 + 10L/ 1000) μm (L: measuring length in mm) (Varies with scale SL 110/130)								
Resolution					10, 20, 25,	50, 100 μm				
Alarm display		LED turns orange. (green for normal operation)								
Output circuit			ector Max.rated v .rated current:100	0		AB phase signal by line driver (compliance EIA-422)				
Max. response speed					300 r	n/ min				
Clearance (inch)					Max. 1.5 r	nm (0.059)				
Power supply			DC 10 ~ 30 V					DC 5 V ± 5 %		
Power consumption		Max. 70 mA (2.1 W) Max. 300 mA (1.5 W)								
Protective design grade		Equivalent to IP67 (exclude head cable)								
Operating temperature					0 °C to 45 °C /	32 °F to 113 °F				
Storage temperature		-20 °C to 50 °C / -4 °F to 122 °F								



Unit : mm/inch




- Compact ribbon type scale for easy mounting in cramped spaces
- Non-contact detection
- Magnetic detection system with excellent resistance to dust, oil, vibrations and shocks.
- Effective length from 50 mm to 100,000 mm

\*Mount the scale on the non-magnetic material. When mounting on a magnetic material, insert a non-magnetic layer with a thickness of at least 3mm.

[Reader head]

PL101-N/R/RH

- Detects linear displacement and produces analog or AB quadrature signal output when connected to PL101 head and MJ500/600/620 Series interpolator (both sold separately).
- Three types are available with different reference point specifications.





Configurations


[Scale]

No reference point

One reference point

Multi reference point


Reference mark



[Interpolator]

[Output]





Unit : mm/inch

Reference mark pitch(p)	Effective length (mm)
80 mm	200 <ml≦2,000< td=""></ml≦2,000<>
160 mm	2,000 <ml≦12,000< td=""></ml≦12,000<>
320 mm	12,000 <ml≦56,000< td=""></ml≦56,000<>
480 mm	56,000 <ml≦100,000< td=""></ml≦100,000<>

### The relation of Effective length (L) and factor N

The relation of Ellective length (L) and factor in								
L:m	Ν	L:m	Ν	L:m	Ν	L : m	N	
3 <ml≦5.5< td=""><td>1</td><td>28<ml≦30.5< td=""><td>11</td><td>53<ml≦55.5< td=""><td>21</td><td>78<ml≦80.5< td=""><td>31</td></ml≦80.5<></td></ml≦55.5<></td></ml≦30.5<></td></ml≦5.5<>	1	28 <ml≦30.5< td=""><td>11</td><td>53<ml≦55.5< td=""><td>21</td><td>78<ml≦80.5< td=""><td>31</td></ml≦80.5<></td></ml≦55.5<></td></ml≦30.5<>	11	53 <ml≦55.5< td=""><td>21</td><td>78<ml≦80.5< td=""><td>31</td></ml≦80.5<></td></ml≦55.5<>	21	78 <ml≦80.5< td=""><td>31</td></ml≦80.5<>	31	
5.5 <ml≦8< td=""><td>2</td><td>30.5<ml≦33< td=""><td>12</td><td>55.5<ml≦58< td=""><td>22</td><td>80.5<ml≦83< td=""><td>32</td></ml≦83<></td></ml≦58<></td></ml≦33<></td></ml≦8<>	2	30.5 <ml≦33< td=""><td>12</td><td>55.5<ml≦58< td=""><td>22</td><td>80.5<ml≦83< td=""><td>32</td></ml≦83<></td></ml≦58<></td></ml≦33<>	12	55.5 <ml≦58< td=""><td>22</td><td>80.5<ml≦83< td=""><td>32</td></ml≦83<></td></ml≦58<>	22	80.5 <ml≦83< td=""><td>32</td></ml≦83<>	32	
8 <ml≦10.5< td=""><td>3</td><td>33<ml≦35.5< td=""><td>13</td><td>58<ml≦60.5< td=""><td>23</td><td>83<ml≦85.5< td=""><td>33</td></ml≦85.5<></td></ml≦60.5<></td></ml≦35.5<></td></ml≦10.5<>	3	33 <ml≦35.5< td=""><td>13</td><td>58<ml≦60.5< td=""><td>23</td><td>83<ml≦85.5< td=""><td>33</td></ml≦85.5<></td></ml≦60.5<></td></ml≦35.5<>	13	58 <ml≦60.5< td=""><td>23</td><td>83<ml≦85.5< td=""><td>33</td></ml≦85.5<></td></ml≦60.5<>	23	83 <ml≦85.5< td=""><td>33</td></ml≦85.5<>	33	
10.5 <ml≦13< td=""><td>4</td><td>35.5<ml≦38< td=""><td>14</td><td>60.5<ml≦63< td=""><td>24</td><td>85.5<ml≦88< td=""><td>34</td></ml≦88<></td></ml≦63<></td></ml≦38<></td></ml≦13<>	4	35.5 <ml≦38< td=""><td>14</td><td>60.5<ml≦63< td=""><td>24</td><td>85.5<ml≦88< td=""><td>34</td></ml≦88<></td></ml≦63<></td></ml≦38<>	14	60.5 <ml≦63< td=""><td>24</td><td>85.5<ml≦88< td=""><td>34</td></ml≦88<></td></ml≦63<>	24	85.5 <ml≦88< td=""><td>34</td></ml≦88<>	34	
13 <ml≦15.5< td=""><td>5</td><td>38<ml≦40.5< td=""><td>15</td><td>63<ml≦65.5< td=""><td>25</td><td>88<ml≦90.5< td=""><td>35</td></ml≦90.5<></td></ml≦65.5<></td></ml≦40.5<></td></ml≦15.5<>	5	38 <ml≦40.5< td=""><td>15</td><td>63<ml≦65.5< td=""><td>25</td><td>88<ml≦90.5< td=""><td>35</td></ml≦90.5<></td></ml≦65.5<></td></ml≦40.5<>	15	63 <ml≦65.5< td=""><td>25</td><td>88<ml≦90.5< td=""><td>35</td></ml≦90.5<></td></ml≦65.5<>	25	88 <ml≦90.5< td=""><td>35</td></ml≦90.5<>	35	
15.5 <ml≦18< td=""><td>6</td><td>40.5<ml≦43< td=""><td>16</td><td>65.5<ml≦68< td=""><td>26</td><td>90.5<ml≦93< td=""><td>36</td></ml≦93<></td></ml≦68<></td></ml≦43<></td></ml≦18<>	6	40.5 <ml≦43< td=""><td>16</td><td>65.5<ml≦68< td=""><td>26</td><td>90.5<ml≦93< td=""><td>36</td></ml≦93<></td></ml≦68<></td></ml≦43<>	16	65.5 <ml≦68< td=""><td>26</td><td>90.5<ml≦93< td=""><td>36</td></ml≦93<></td></ml≦68<>	26	90.5 <ml≦93< td=""><td>36</td></ml≦93<>	36	
18 <ml≦20.5< td=""><td>7</td><td>43<ml≦45.5< td=""><td>17</td><td>68<ml≦70.5< td=""><td>27</td><td>93<ml≦95.5< td=""><td>37</td></ml≦95.5<></td></ml≦70.5<></td></ml≦45.5<></td></ml≦20.5<>	7	43 <ml≦45.5< td=""><td>17</td><td>68<ml≦70.5< td=""><td>27</td><td>93<ml≦95.5< td=""><td>37</td></ml≦95.5<></td></ml≦70.5<></td></ml≦45.5<>	17	68 <ml≦70.5< td=""><td>27</td><td>93<ml≦95.5< td=""><td>37</td></ml≦95.5<></td></ml≦70.5<>	27	93 <ml≦95.5< td=""><td>37</td></ml≦95.5<>	37	
20.5 <ml≦23< td=""><td>8</td><td>45.5<ml≦48< td=""><td>18</td><td>70.5<ml≦73< td=""><td>28</td><td>95.5<ml≦98< td=""><td>38</td></ml≦98<></td></ml≦73<></td></ml≦48<></td></ml≦23<>	8	45.5 <ml≦48< td=""><td>18</td><td>70.5<ml≦73< td=""><td>28</td><td>95.5<ml≦98< td=""><td>38</td></ml≦98<></td></ml≦73<></td></ml≦48<>	18	70.5 <ml≦73< td=""><td>28</td><td>95.5<ml≦98< td=""><td>38</td></ml≦98<></td></ml≦73<>	28	95.5 <ml≦98< td=""><td>38</td></ml≦98<>	38	
23 <ml≦25.5< td=""><td>9</td><td>48<ml≦50.5< td=""><td>19</td><td>73<ml≦75.5< td=""><td>29</td><td>98<ml≦100< td=""><td>39</td></ml≦100<></td></ml≦75.5<></td></ml≦50.5<></td></ml≦25.5<>	9	48 <ml≦50.5< td=""><td>19</td><td>73<ml≦75.5< td=""><td>29</td><td>98<ml≦100< td=""><td>39</td></ml≦100<></td></ml≦75.5<></td></ml≦50.5<>	19	73 <ml≦75.5< td=""><td>29</td><td>98<ml≦100< td=""><td>39</td></ml≦100<></td></ml≦75.5<>	29	98 <ml≦100< td=""><td>39</td></ml≦100<>	39	
25.5 <ml≦28< td=""><td>10</td><td>50.5<ml≦53< td=""><td>20</td><td>75.5<ml≦78< td=""><td>30</td><td></td><td></td></ml≦78<></td></ml≦53<></td></ml≦28<>	10	50.5 <ml≦53< td=""><td>20</td><td>75.5<ml≦78< td=""><td>30</td><td></td><td></td></ml≦78<></td></ml≦53<>	20	75.5 <ml≦78< td=""><td>30</td><td></td><td></td></ml≦78<>	30			

Specifications								
Model	SL700	SL710	SL720	SL730				
Reference point	No reference point	One point (Specify the position when ordering) (1 mm unit)	Multi point 60mm pitch from left effective length end	Reference mark (Refer to figure below)				
Reference point position accuracy	-	±1 mm	± 1 mm Pitch accuracy ± 7 μm	± 1 mm Pitch accuracy ± 7 μm				
Effective length (L)*	50 to 100	),000 mm	100 to 100,000 mm	200 to 100,000 mm				
Overall length		L+40	Omm					
Accuracy (20 °C)	± 10L μm (L≦3m) ± (10L+2.5N) μm (L >3m) *In combination with PL101 series *L Measuring length *Refer separate table							
Reproduced wave length		800	Ĵμm					
Single mass		15	g/m					
Linear expansion coefficient		(14 ± 1) × 10 <sup>-6</sup>	/ °C (Scale unit)					
Operating temperature		0 to 45 °C / 3	32°F to 113°F					
Storage temperature		-20 to 50 °C /	/ -4°F to 122°F					
Standard compliance								


\*L≤1,000mm:50mm pitch 1,100≤L≤3,000mm:100mm pitch 3,500≤L≤10,000mm:500mm pitch 11,000≤L:1,000mm pitch


PL	PL10 Head cable unit
Non-contact detection	


- Magnetic detection system for excellent resistance to dust, oil, vibrations and shocks.
- Detects linear position and displacement and produces analog signal output when connected to the SL700 Series. Produces AB quadrature signal when connected to MJ500/600 Series interpolator
- A wide range of models is available so you can select the best model for your specific application.

### Example for connection

Estample for connocid			
Scale			Interpola
SL700	PL101	CE08	MJ500/600/620/700 MJ8
Dimensions			








Model		PL101-N	PL101-R	PL101-RH	
Protective grade		Ec	guivalent to IP50	Equivalent to IP67 (exclude Connecter)	
Reference point	detection function	Not Included	Inclu	ıded	
Resolution (Connected to MJ500 and MJ600/620)		1, 2, 5 or 10 μm (MJ620), 1 μm (MJ600), 2 or 10 μm (MJ500)			
Accuracy (20 °C	2)		$\pm$ 10 $\mu$ m (when combined with the SL700)		
Clearance*		$2.5 \pm 0.1$ mm			
Offset			± 0.2 mm		
	Pitch*	± 0.1°			
Attitude change	Yaw*		± 0.2°		
change -	Roll*	± 0.2 <sup>2</sup>			
Output signal		Differential output Sin, C - Sin,- Cc Z,*		0 0.52 0.70 0 0.68 1.00 800 -	
Power supply v		DC 5V ± 5%			
Power consum		Max. 150 mA (0.8W)			
Max. response	speed	6.4 m/s			
Cable length			300 mm	3000 mm	
Mass			60 g /2.12oz	150 g / 5.29oz	
Operating temperature			0 to 45 °C / 32F° to 113° F		
a		-20 to 50 °C / -4°F to 122° F			
Storage temper Standard comp			-2010 50 C7 -4 F to 122 F Class A EMS: EN50082-2 FCC Part 15 Subpart B Class A ICES		

\*Refer to Dimensions drawings below. \*Cable length of more than 15m,Please consalt our sales.





Unit · mm/inch

# Digital Scales

**Rotary scale** 

RU77 RS310

## **RU77**


High precision absolute rotary type with exellent resistance to environments.

	<u>с</u> ,	(ctam	accuracy		C	) Sear
~		JOLEIII	accurac	у.	<u> </u>	


- Output wave number :
- $2^{12} = 4,096$
- Output pulse number :
- 2<sup>25</sup> = 33,554,432 p.p.r.
- Low-profile shape : 42mm
- Protocol : FANUC, Mitsubishi, YASKAWA

### Specifications

Output signal	Absolute serial
Detection system	Мад
System accuracy (at 20 °C)	
Resolution	Approx.2.5°/1,000 - Approx.1°/10
Output wavelength	
Output wave number	
Number of divisions	
Electrical allowable revolution	
Mechanical allowable revolution	
Operating temperature range	
Storage temperature range	
Vibration resistance	15
Shock resistance	
Protective design grade	
Power supply voltage	DC 4.75 -
Current consumption	200m
Inrush current	2 A max. (When
Power supply protection	In the case of errors such as the internal fuse is cut to
Safety standards	FCC Part15 Subpart B Class A, ICES-003 Safety standa
Dimensions	
Cable length	Standard 1 m (maxir
Output connector	Male, round waterproof connector
Compliant connector	Female, round waterproof connected
Moment of inertia	
Starting torque (at 20 °C)	
Mass	



### Details of model designation





RU77-4096AXX
I (2/4 duplex: Compliant with EIA-422)
gnetic system (MR sensor)
±2.5"
0,000 (131,072pulse/rotation - 33,554,432pulse/rotation)
40 mm (λ)
4,096 waves/rotation
4,096
2,000min <sup>-1</sup>
3,000min <sup>-1</sup>
0 ~ +60 °C
-10 ~ +60 °C
50m/s²(50Hz ~ 2,000Hz)
1,000m/s²(11ms)
IP65
5.25 V (At cable connection end)
nA (at 120 $\Omega$ terminal) or less
the power supply rising time is 10 ms)
a reverse-connected power supply or over-voltage,
o protect the power being supplied and wiring.
Class A Digital Device and EN55011 Gp1 Class A, EN61000-6-2. ards not applicable (60 V DC or less)
ø110 x 42mm
mum length of 15 m with extension cables)
or NJB1DB 10PL2 by Japan Aviation Electronics Industry
tor NJB1HB 10SL2 by Japan Aviation Electronics Industry
9.4 x 10 <sup>-5</sup> kgm <sup>2</sup>
0.1 N.m or less
Approx.1.3kg

tion	Pulse number/ Revolution	Number of partitions	Туре	
00	131,072	1/32	Α	
	262,144	1/64	В	
0	524,288	1/128	С	
000	1,048,576	1/256	D	
0	2,097,152	1/512	E	
0	4,194,304	1/1024	F	
,000	8,388,608	1/2048	G	
00	16,777,216	1/4096	Н	
00	33,554,432	1/8192	J	

	NC Manufacturer	Wire	
_	FANUC	4	А
	Mitsubishi	2	В
	WIIISUDISHI	4	D
	YASKAWA	2	F


Note:YASKAWA controler is only D \*Polarity is CCW



### Example for connection

	Cable	Interpolator
RS310	AK2-C	MD20B

### System configuration



Rotation drive mechanism

# Interpolators

Specifica	tions		
Model		RS310-1800A	
No. of reader	heads	1	
No. of recorde	ed waves	1800 λ / revolution	
Recorded wave length		0.32 mm	
Resolution		0.001°	
Clearance		100 to110 µm (recommended)	
Cumulative pitch accuracy *1		7.2"	
Interpolation accuracy		3.6***2	
Allowable scale drum runout		Keep to min. at installation*1	
Allowable head	mounting face flatness	5 μm or less (No burs or unevennesses)	
Allowable residu	ual machine magnetism	0.25 mT	
Max. mechan	ical revolutions	7000 min <sup>-1</sup>	
	Dimensions	ø 183.4 x ø 121 x 16 mm (ø 7.23" x ø 4.77" x 0.63") (Outer dia . x inner dia. x thickness)	
Scale drum	Mounting pitch dia	ø 132 mm/ 5.20*	
Codio Grann	Mass	Approx. 1.6 kg/ 3.53 lbs	
	Moment of inertia	1.12 x 10 <sup>-2</sup> kg m <sup>2</sup>	
Diameter excl	. cable guide	Max. approx. ø 235 mm/ 9.26*	
Operating ten	nperature	0 °C to 40 °C/ 32 °F to 104 °F	
Storage temp	erature	-10 °C to 50 °C/ 14 °F to 122 °F	
Reader heads	Mass	Approx. 0.12 kg/ 0.26 lbs	
1100031110003	Cable length	300 mm/ 11.8*	

\*1 RS310-1800A Cumulative pitch error will be less than 7.2" with circumference eccentricity of 3 μm More eccentricity, Add 2.3"/1μm

RS310-1800B Cumulative pitch error will be less than 7.2\* with circumference eccentricity of 30 µm. Total accuracy is sum of cumulative pitch error and interpolation error

\*2 3.6" interpolation error for 1.5% of PM signal ripple

MJ100/110 MJ620 MJ820/821 MJ830/831




## MJ100/110

High response speed interpolator unit for position control

- Capable of 40 to 1000 divisions
- Produces AB quadrature signals with a resolution from 2 μm to 125 μm, when used in combination with the optionally available Digiruler® PL25 head unit and the SL110/130 scale unit (scale signal wavelength: 5 mm), or with the PL60 and the SL331 scale unit (scale signal wavelength: 2 mm).
- MJ100: Supply voltage 5 V input, Line driver (EIA-422 compliance) output
- MJ110: Supply voltage 12 to 30 V input, Open collector (IoL=50 mA) output
- MJ100 also generates U/ V/ W phase output with a period of reproduced Digiruler₀ signal (5 mm with PL25; 2 mm with PL60)

### Example for connection



Unit : mm/inch

Specificat	ions			
Model		MJ100	MJ110	
Power supply		5 V (4.5 V to 6 V)	12 V to 30 V (11 V to 31 V)	
Power consum	nption	4 W	3 W	
Output interfac	e	Line driver (EIA-422 compliance)	Open collector (IoL = 50 mA max.)	
Outputs		AB quadrature, Z phase, U/V/W phases, alarms	AB quadrature, Z phase, alarms	
Number of divisions		1000,960,800,512,500,480,400,256,240,200,128,120,100,80,64,40 and 1/2 of each of these (which does not satisfy the synchronized reference point specifications.)		
	1000 divisions	6 KHz (1800 m/min when connected to PL25; 720 m/min when connected to PL60)	600 KHz (180 m/min when connected to PL25; 72 m/min when connected to PL60) *1	
Maximum	500 divisions	15 KHz (4500 m/min when connected to PL25; 1800 m/min when connected to PL60)	1.5 KHz (450 m/min when connected to PL25; 180 m/min when connected to PL60) *1	
response frequency	200 divisions	42 KHz (12600 m/min when connected to PL25; 5000 m/min when connected to PL60)	4.0 KHz (1200 m/min when connected to PL25; 480 m/min when connected to PL60) *1	
noquonoy	120 divisions	70 KHz (21000 m/min when connected to PL25; 8400 m/min when connected to PL60)	7.4 KHz (2220 m/min when connected to PL25; 888 m/min when connected to PL60)*1	
Minimum phas	e difference	100 ns	1µs	
Alarms *2		Speed alarm (minimum phase difference time or maximum response frequency); Level alarm (0.4 Vp-p or less); Minimum alarm time: approximately 400 ms		
System startup	o time	Within 0.5 seconds after the power comes on line		
External dimen	isions	138 x 93 x 26 (mm) / 5.43" x 3.66" x 1.02" including protrusions		
Compatible he	ad unit	PL25 or PL60		
Operating tem	perature	0 °C to +45 °C / 32 °F to 113 °F		
Storage tempe	erature	-20 °C to +60 °C / -4 °F to 140 °F		
Mass		350g/ 0.77lbs		
Supplied acces	ssories	Manual, output connector, co	nnector cap, mounting screws	
Options			nsion cable, external reference point extension cable ctor with cable	


SL331

\*1: These values for a minimum phase difference of 1 µs may vary depending on the output cable length. \*2: The alarm function may not operate when an abnormal offset is generated due to a broken wire, etc.

\*Contact us directly if you have special requirements for the specifications



Phase Relation between MJ100 Input Signals, U/V/W Phases and AB Phases



MJ110

PL60




### $\mathbb{N}$ Compact one-axis module with analog input port

- Divides analog input signal into 32 to 800 divisions.
- Produces AB quadrature signal output from the differential line
- driver when combined with SL700 series scale and PL101 series head cable (both sold separately).

	Head	Cable	Interpolator
SL700	PL101	CE08 CK-T12/13/14/15/16	MJ620






Specifications		
Model	MJ620	
Power supply voltage	5 V (4.5 to 6 V)	
Power consumption	2.2 W (with PL101)	
Output interface	Line driver (EIA-422 compliance)	
Output	AB quadrature, Z, Alarm	
Number of division	800,400,160,80,40,32 (Correspond to resolution 1,2,5,10,20,25 μm) And 1/2 of this (But concurrent reference point not satisfied)	
	6.4 m/s (with phase difference of 100 ns and resolution of 1 μm)	
Mar	16 m/s (with phase difference of 100 ns and resolution of 2 μm)	
Max. response speed	36.8 m/s(with phase difference of 100 ns and resolution of 5 μm)	
	56 m/s (with phase difference of 100 ns and resolution of 10 μm)	
Min. phase difference	ference 100 ns	
Input level	SIN. COS signal 0.6 Vp-p to 1.2 Vp-p at 120 Ω load Reference signal 0.2 V to 1.5 V at 120 Ω load	
Alarm Speed alarm (min. phase difference time or max. response frequency), Level alarm (0.6 Vp-p or less), Min. alarm time about 400 ms NOTE: Alarm may not work due to abnomal offset occurred by breakage etc.		
System starting up time	0.5s or less after powering up	
Operating temperature	0 °C to +45 °C / 32 °F to 114 °F	
Storage temperature	-20 °C to +60 °C / -4 °F to 140 °F	
Mass	60 g/ 2.12 oz	


Options

MZ2: Output connector MZ5: Metal case for MJ620

\*The MJ620 Interpolator meets the \*applied standards\* stated in the specifications table when fitted with the optional MZ5 metal case (see below). Make sure that the MJ620 is used with the MZ5 or like case with the same specifications as MZ5.



MZ5(Option)



Unit · mm/inch




## MJ820/821


Generalized interpolator with serial-interface output for FANUC CNCi series and its successor models


- Connectable to any general analog-output encoder. Input impedance: 120  $\Omega$  1 Vp-p voltage differential input
- Max. response frequency 140 kHz for any number of divisions selected • Switch-selectable number of divisions:40,80,100,120,160,200,240,400, 480,500,800,1000,1600,2000,3200,4000
- Compensation: DC offset, gain and phase
- Power supply: DC 5V (4.5 to 5.5 V) for MJ820; DC 12V to 24V (11V to 32V) for MJ821
- Compatible with Sony's Digital scales SL700 series with PL101

### Example for connection









.

):...

SPE MIN

Unit : mm/incl

Specifications						
Model	MJ820	MJ821				
Power						
Power supply voltage	DC5 V (DC4.5 to 5.5 V)	DC12 to 24V (DC11 to 32 V)				
Power consumption	3	3 W				
Input power supply rise time	100 ms					
Surge current (10ms)	4A or less (with 5 V)	3A or less (with 12 V)				
Power supply reverse connection prevention	Fi	Fuse				
Communication						
I/F input/ output circuit	t/ output circuit Voltage-differential line driver/ receiver complying with EIA-422 (SN75C1167 or equivalent)					
Communication protocol	Dedicated Fanuc serial interface protocol					
Interpolator						
Encoder input signal	1Vp-p (Max.1.2Vp-p) impedance 120 Ω TYP					
Selectable division settings	4000,3200,2000,1600,1000,800,500,480,400,240,200,160,120,100,80,40					
Maximum response frequency for encoder input	140 kHz*1					
Alarms	"1" is sent to a designated flag at time of speed alarm and level warning*2 All LEDs flash at the time of compensated data backup error*3					
Operating temperature and humidity range	0 to 55 °C (no condensation)					
Storage temperature and humidity range	-20 to 65 °C (20 to 90%RH)					
Mass	380 g /	0.84 lbs				
Accessories	Power supply plug1 (MJ821 only) Connector cap1 Supplement1 Binding band1 (MJ821 only) Ferrite core1 Mounting screws (4 x 10)2					

\*1: 140 kHz applies when sine and cosine signals within a designated range are applied to MJ820/821. Max. response frequency may be lower than 140kHz with change in input signal level or off-set value.


\*2: Speed alarm is triggered when max. response speed is exceeded or at the time of erroneous counting due to noise. Level warning is triggered when the sine and cosine signal input level is lower than 0.6 to 0.5Vp-p. \*3: All LEDs light at the next power-on in case, at the time of data compensation, the compensated data was not correctly backed up.



- Connectable to any general analog-output encoder. Input impedance: 120  $\Omega$  1 Vp-p voltage differential input
- Max. response frequency 140 kHz for any number of divisions selected
- Switch-selectable number of divisions: 40,80,100,120,160,200,240,400, 480,500,800,1000,1600,2000,3200,4000
- Compensation: DC offset, gain and phase
- Power supply: DC 5V (4.5 to 5.5V) for MJ830; DC 12V to 24V (11V to 32V) for MJ831
- Compatible with Sony's Digital scales SL700 series with PL101

### Example for connection

	Head	Cable	Interpolator
SL700	PL101	CE08 CK-T12/13/14/15/16	MJ830/831




Vodel	MJ830	MJ831			
Power					
Power supply voltage	DC5 V (DC4.5 to 5.5 V) DC12 to 24V (DC11 to 32 V)				
Power consumption	3	3₩			
Input power supply rise time	100	100 ms			
Surge current (10ms)	4A or less (with 5 V)	3A or less (with 12 V)			
Power supply reverse connection prevention	Fu	Fuse			
Communication					
I/F input/ output circuit	Voltage-differential line driver/ receiver complying with EIA-422 (SN75C1167 or equivalent)				
Communication protocol	Dedicated Mitsubishi Electric Corp. serial interface protocol				
Interpolator					
Encoder input signal	1Vp-p (Max.1.2Vp-p) impedance 120 Ω TYP				
Selectable division settings	4000,3200,2000,1600,1000,800,500,480,400,240,200,160,120,100,64,40				
Maximum response frequency for encoder input	140 kHz* <sup>1</sup>				
Alarms	*1* is sent to a designated flag at time of speed alarm and level warning*2 All LEDs flash at the time of compensated data backup error*3				
Operating temperature and humidity range	0 to +55 °C (no condensation)				
Storage temperature and humidity range	-20 to +65 °C (20 to 90%RH)				
Mass	380 g / 0.84 lbs				
Accessories	Power supply plug1 Connector cap1 Supplement1 Binding band1 Ferrite core1 Mounting screws (4 x 10)2				

\*2: Speed alarm is triggered when max. response speed is exceeded or at the time of erroneous counting due to noise. Level warning is triggered when the sine and cosine signal input level is lower than 0.6 to 0.5Vp-p. \*3: All LEDs light at the next power-on in case, at the time of data compensation, the compensated data was not correctly backed up







16.01E



## List of Adopter Cables (SR80, SR70, RU77 Series)

	Protocol	Output	Connector type on controller side	Provision of gro Not provided	unding wire Provided	Contour		Connection connector on scale side*	Model
		Spread-out end	Spread-out end	Not provided			0	Standard	CH33-**○▽
	Standard					┉┈┈╢╢╢╗	0	For relaying (JN2DS10SL2-R)	CH33-**○▽ZA
		A quad B signal	3M 10P Model: Receptacle: 36210-0100PL Shell kit: 36310-3200-008	L			0	Standard	CH33-**○▽L
							0	For relaying (JN2DS10SL2-R)	CH33-**○▽LA
	Mitsubishi			М			0	Standard	СН33-**⊖▽М
		ABS and INC serial					9	For relaying (JN2DS10SL2-R)	CH33-**○▽MA
e							0	Standard	CH33-**○▽E/P
cale us		A quad B signal Honda Tsushin Kogyo 20P		E	P		0	For relaying (JN2DS10SL2-R)	CH33-**○▽EA/PA
Straight line scale use		ADC and INC agric	Straight case Model: PCR-S20-FS+	F	Q		0	Standard	CH33-**⊖⊽F/Q
traight	Fanua	ABS and INC serial					٢	For relaying (JN2DS10SL2-R)	CH33-**⊖⊽FA/QA
	Fanuc	A guad D signal	Hirose Electric 20P Horizontal drawing case Model: FI40B-20C-CVS5(50)	н	R			Standard	CH33-**○▽H/R
		A quad B signal						For relaying (JN2DS10SL2-R)	CH33-**⊖⊽HA/RA
		ABS and INC serial		L	S			Standard	CH33-**○▽J/S
								For relaying (JN2DS10SL2-R)	CH33-**⊖⊽JA/SA
	Panasonic,	ABS and INC serial	Molex 6P Model: 55100-0670	G	_			Standard	CH33-**○▽G
	Yaskawa					▋▝ <u><u></u><u></u></u>	٢	For relaying (JN2DS10SL2-R)	CH33-**○▽GA
	Connection cable for relaying	-	Japan Aviation Electronics 10P Model: JNIHS10PLS	К	-	\$ 1] <del>8</del>	0	Standard	СН33-**⊖⊽К
ŝe	Cable with its end spread out	Spread-out end	Spread-out end	_	_		۲	JAE JB1 (female) JB1HB 10SL2	JAE JB1 (female)
Rotary scale use	Extension cable	Compatible with all RU77 models	JAE JB1 (male) JB1DB 10PL2	-	-		۲	JAE JB1 (female) JB1HB 10SL2	CE28-***OJ
otary s	Mitsubishi Electric	ABS serial	3M Receptacle: 36210-0100PL Shell kit: 36310-3200-008	-	_		-	JAE JB1 (female) JB1HB 10SL2	CE28-***OM
Ē.	Fanuc	ABS serial	Honda Tsushin Kogyo Plug: PCR-S20FS+ Plug case: PCR-LS20LA	-	_		•	JAE JB1 (female) JB1HB 10SL2	CE28-***OF
	YASKAWA	ABS serial	Molex 6P Model: 55100-0670	_	-		•	JAE JB1 (female) JB1HB 10SL2	CE28-***OG





\* If the scale-side connection connector for relaying uses a relaying connector, please use this cable.

\* The standard cable is not A quad B signal. Please consult our local sale office for detail.

## Connection Cable for Feedback scale

### [linear Scale]

	Scale	Head	Cable	Interpolator
	SL110/130	PL25	CE08-1/3/5/10/15 CK-T12/13/14/15/16	MJ100/110
DIGIRULER⊚		PL80	-	-
	SL331	PL60	CE08-1/3/5/10/15 CK-T12/13/14/15/16	MJ100/110
	SL700	PL101	CE08-1/3/5/10/15 CK-T12/13/14/15/16	MJ500/600/620/700 MJ820/821 MJ830/831

### [Rotary Scale]

Scale		Cable	Extension Cable	Interpolator
Incremental Scale	RS310	KA2-**C	EK2-**C	MD20B

KA2-\*\*C EK2-\*\*C

### Safety No compromise for high-accuracy products







Isehara plant is registered to ISO 9001 (Quality)

Our products comply with CE Marking requirements, have acquired UL certifications and meet other regulations, ensuring safe use the world over. We have met:

• EMC Directives(CE) EMI: EN 55011 Group 1 Class A / 91 EMS: EN 61000-6-2

• FCC regulation FCC Part 15 Subpart B Class A

for Products with built-in AC power supply:

• UL 61010-1

\* When using our devices with machines to which the European Machinery Drirective applies, please make sure that the devices when installed on the machines fulfil the applicable requirements of the Directive.

\* Standards or regulations to be complied with may vary by product.

The total quality control system that operates throughout the entire design and production process ensures products with enhanced safety, high quality, and high reliability that match our customers' requirements. The company is certified for length calibration in compliance with the traceability system required by the "Weights and Measures Act," and has been granted ISO 9001 certification, which is the international standard for quality



for Products with Laser: • DHHS Class 1 (21CFR1040.10)

### http://www.mgscale.com

Magnescale

